

# Breakdown Of UPS Components

The following is a breakdown of the parts and accessories that comprise the PowerGrid 800 UPS Configurations

PG800 UPS: 800W Tactical UPS

PG-LBI-DC: Load Balancing Interconnect Cable (Used when Stacking UPS Modules)

PG-IPC-25F: Input Power Connection Cable (25') (Included with UPS each UPS purchase)

PG-PIC-6F: Power Interconnect Cable (6')

PG-PIC-2F: Power Interconnect Cable (2')

PG-RPIM-STD: Standard Remote Power Interconnect Module (Standard with 6 NEMA 5-15R Receptacles)

PG-RPIM-LBI-STD: Power Combining RPIM Standard (Used when Stacking UPS Modules) (Standard with 6 NEMA 5-15R Receptacles)

PG-RPIM-LBI-XXXXXX: Power Combining RPIM Modified (Customer Selected Connection Style) (MIL Circular/NEMA 5-15R/NEMA 5-15F)

PG-EMI-FP: EMI Filter Pack (Optional)

PG-BXM: Battery Expansion Module (Optional) (Extends Hold Time to +30 Minutes)

PG-BXM-PIC: BXM Power Interconnect Cable (Required to interconnect BXM to UPS)

